

# Wood Duck Box Mounting Bracket

Cut a 30" section from your pressure treated 2 x 4.



Cut a 6" section from your pressure treated 2 x 4.



Mark the 30" section at the midpoint.



Mark the 6" section at the midpoint.



Align the marks and attach the two sections with screws.



On one end, mark and drill holes to match the spacing of the metal sign post.



On the opposite end, drill 2 holes to attach the mounting bracket to the Wood Duck box. These holes should align with holes drilled in the back of the Wood Duck box. Drill all holes slightly larger than the bolts supplied.

